

Think Controls

FOTEK

Self-adaptive Fuzzy + PID

Temperature Controller

NT series

§ Intelligence
§ Performance
§ Reliability
§ Easiness
§ Stability
§ Sensitivity

Complete Human- interface & Function

- ＊ 輸出量顯示
- ＊ 負載電流量顯示
- ＊ 關閉控溫功能
- ＊ 快速自動演算鍵
- ＊ 緩衝起動功能
- ＊ 加熱斜率控制
- ＊ 手動輸出控制
- ＊ 全機種可附通訊功能

- ＊ Output volume display
- ＊ Load current display
- ＊ Turn off control function
- ＊ Fast auto-tuning setting
- ＊ Soft start function
- ＊ Ramp control function
- ＊ Manual output control function
- ＊ Communication function available

CE RoHs

陽明電機股份有限公司
FOTEK CONTROLS CO., LTD.

Model guiding / 型號索引

Ex. NT – 48 R – CT – RS
(1: NT; 2: 48; 3: R; 4: CT; 5: RS)

1	Series (系列名稱)	NT: New generation Temperature controller
2	Outline (外形) (Unit: mm)	20: 48*96*60　21: 96*48*60　22: 22.6*75*100 48: 48*48*72　72: 72*72*60　96: 96*96*60
3	Output method (輸出方式)	R: Relay (3A/250VAC)　V: SSR (20mA/12V)　L: Linear output (4~20mA)
4	Optioned (附加功能)	CT: With Heater break detecting　mA: DC current input　mV: DC Voltage input
5	Optioned (附加功能)	RS: With RS-485 communication (MODBUS protocol)　S: PV transmitter

How to set the function or parameter / 如何設定功能及參數

1. 「Temperature setting status」: Press「**SET**」key instantaneously to enter into the temperature setting status.
2. 「Auto-tuning status」: Press「▲」key 3 sec to set「Auto-tuning」,then press「▲」key 3 sec to reset it.
3. 「Manu-output status」: Press「▼」key 3 sec to turn off the output control, then press the「**SET**」key to set the 「Manu-output volume」If press「▼」key 3 sec may to release「**Manu-output status**」
4. 「Display mode selecting」: Press「**SET**」key 3 sec to select display mode
   4-1.Without CT type: Display「Output volume」(u.xx)→then press「**SET**」key 3 sec → to display「Temperature set value」
   4-2. With CT type: Display「output volume」(u.xx)→then press「**SET**」key 3 sec → to display「Load current」(xx.xx)
   →then press「**SET**」key 3 sec → to display「Temperature set value」
5. 「Parameter setting status」: Press「**F**」key 3 sec to enter into the parameter setting status.
6. 「Alarm setting status」: Press「**SET**」&「**F**」key 3 sec to enter into the Alarm setting status.
7. 「Communication stetting status」: Press「**SET**」&「▼」key 3 sec to enter into the Communication stetting status.
8. 「Soft start function」: At the final parameter of「setting of alarm」, Press「**SET**」key 3 sec to set the **Soft start setting value**「**SV2**」.
   the fixed output volume is set by the manual output volume.
9. 「Ramping control」: At the「rAP」 parameter in the「setting of alarm」level, if「rAP = 0」, it has not the ramping control function.
   if「rAP≠0」, it will perform the ramping control function.
10. 「Display mode setting」: At the「Sdc」 parameter in the「**Setting of parameter**」level, if「Sdc = n」, it will be kept on the selected display mode, if「Sdc = A」, it will be returned to the Temperature set value mode after 10 seconds.

1. 「溫度值設定狀態」：按「**SET**」鍵一下就可進入「溫度值設定狀態」
2. 「自動演算狀態」：按「▲」鍵3秒可進入「自動演算狀態」；再按「▲」鍵3秒解除「自動演算狀態」
3. 「手動輸出控溫狀態」：按「▼」鍵3秒關閉輸出（顯示「OFF」），再按「**SET**」鍵3秒後可設定「手動輸出量」（顯示n.xx），完成手動輸出量設定後如果再按「▼」鍵3秒可解除「手動輸出控溫狀態」回複自動控溫狀態。。
4. 「顯示模式選擇」：按「SET」鍵3秒
   4-1. 無CT型：「輸出量顯示」（**u.xx**）→再按「**SET**」鍵3秒→「溫度設定值顯示」
   4-2. CT型：「輸出量顯示」（**u.xx**）　→再按「**SET**」鍵3秒→「負載電流量顯示」（**xx.xx**）
   →再按「**SET**」鍵3秒→「溫度設定值顯示」
5. 「參數設定」：按「**F**」鍵3秒：進入「參數設定」狀態
6. 「警報設定」：按「**SET**」&「**F**」鍵3秒：進入「警報設定」狀態
7. 「通訊參數設定」：按「**SET**」&「▼」鍵3秒：進入「通訊參數設定」狀態
8. 「緩衝起動設定」：在警報設定的最後一個參數時按「**SET**」鍵3秒可設定「緩衝起動設定值（SV2）」，固定輸出量由手動輸出量設定。
9. 「溫升速率控制」：可設定警報設定層的參數「**rAP**」；「**rAP = 0**」時沒有溫升速率控制功能，「**rAP≠0**」時執行溫升速率控制。
10. 「顯示自動切換設定」：可設定參數設定層的參數「**Sdc**」；「**Sdc = n**」時持續顯示「選擇顯示模式」；「Sdc= A」時10秒後會自動切回「溫度設定值顯示模式」。

General Specification / 共同規格

Fixed method		Panel type					Rail type
Model		NT-48	NT-20	NT-21	NT-72E	NT-96E	NT-22
Outline (U t: mm)	外形尺寸	48*48*72	48*96*60	96*48*60	72*72*60	96*96*60	22.6*75*100
Alarm output	警報輸出	Two alarm					Single alarm
Power supply	工作電壓	90~265 VAC/ 50/60 Hz or 24VDC/AC （Optioned）					
Power consumption	消耗電流	5 VA max. or 100mA max.（24VDC/AC）					
Input method	輸入方式	PT / K / J / R / S / T/ B / E / N / L(Selectable) or 4~mA or 0~10VDC （Optioned）					
Control method	控制方式	Fuzzy + PID or ON / OFF selectable					
Control output	控制輸出	Relay or SSR or 4~20mA (Optioned)					
Alarm output	警報輸出	Relay 1a（5A/250VAC SPDT）					
Display range	顯示範圍	-999 ~ 9999					
Accuracy of display	顯示精度	± (0.1 % OF F.S. + 1 DIGIT)					
Setting range	設定範圍	-999 ~ 9999					
Memory method	記憶方式	EEPROM					
Insulation resistance	絕緣強度	OVER 50MΩ/500VDC					
Dielectric strength	耐壓強度	OVER 2.5 KV/ 1 MINUTE					
Operating circum.	使用環境	–25℃ ~ 80℃ ; 35%~85% RH					
EMC standard	EMC 標準	ESD：8 KV Air Discharge（Level3）/ EN-61000-4-2 RF Interference：10V / M / ENV-50140 Burst test：2KV / EN61000-4-4					

Setting of Communication / 通訊參數設定

Function	Range	Description
	-200 ~ 9999	
	1 ~ 255	1> Range: 1~255
	0 ~ 1	1>「rs=0」: Modbus-RTU 2>「rs=1」: Modbus-ASCII
	96 / 192 / 384	1>「bPS =96」: 9600 bps 2>「bPS =192」: 19200 bps 3>「bPS =384」: 38400 bps
	8N1 / 8E1 8O1 / 7O1	1>「b I t =8N1」: 8 bit non parity 2>「b I t =8O1」: 8 bit odd parity 3>「b I t =8E1」: 8 bit even parity 4>「b I t =8N2」: 8 bit non parity 5>「b I t =7O1」: 7 bit odd parity 6>「b I t =7E1」: 7 bit even parity

Setting of parameter / 參數設定

Function	Range	Description
	-200 ~ 9999 0 ~ 99 0 ~ 1 0 ~ 99 0 ~ 3999 0 ~ 3999 0 ~ 3999 0 ~ 99 0.1~9.9 PT / K / J / R / S T / B / E / N / L ℃ / ℉ 0 ~ 1 - 99 ~ + 99 Htr / cLr 0 ~ 26 n / A	1>「CT = 0」: ON/OFF control 2> Disappeared in Linear output type 1>「At = 0」: Control status 2>「At = 1」: Auto tuning status 1> Auto tuning value =「SV - tu」 1>「CT = 0」→「P」is disappeared 1>「CT = 0」→「I」is disappeared 1>「CT = 0」→「d」is disappeared 1>「CT = 0」→「Hys」is appeared only 2>「PV＞SV）→ Out ON； 〔PV＜（SV-Hys）〕→ Out OFF 1> Gain of output control 1> 10 input type are selectable 1>「**d p = 0**」：Without decimal point 2>「**d p = 1**」：One decimal point 1>「PV」=（PV + Sht） 1>「Htr」：Heating control 2>「cLr」：Cooling control 1> Refer to the mode of Alarm 1>「n」：Manual setting 2>「A」：Auto setting

Setting of alarm / 警報設定

Function	Range	Description
Control status 控制狀態 — 8888 / 8888 Press SET & F key 3 sec	0 ~ 9999	
Lock setting 鎖定設定 — L c k / 0 Press SET	0 ~ 3	1>「Lck=0」: Unlock ; Lck=1」: SV settable only 「Lck=2」: SV&AL settable ;「Lck=3」: All lock
AL1 Limit setting AL1 警報設定 — A L 1 / 50 Press SET	-999 ~ 9999	1> Refer to the mode of Alarm
AL2 Limit setting AL2 警報設定 — A L 2 / 50 Press SET	-999 ~ 9999	1> Refer to the mode of Alarm
Hysteresis of alarm 警報應差值設定 — A L H / 1 Press SET	0 ~ 9999	Ex. PV≧(SV+AL1)→AL1 ON, PV＜(SV+AL1-ALH)→AL1 OFF
Flick timer 警報閃爍輸出時間設定 — t / 10 Press SET	0 ~ 99	1> Range: 0~99 sec 2> Cycle time of flick timer
Setting limit 最大設定值限制 — S L h / 400 Press SET	0 ~ 9999	1> SV≦SLH
Output limit 輸出量限制設定 — O u t / 100 Press SET	0 ~ 100%	1> Output volume = Control output volume *「Out」
Process output volume 實際輸出量 — U n / 0.0 Press SET	0 ~ 99.99	1> Display the output volume
Max. display value setting 最大顯示值設定 — dSPH / 1000 Press SET	0 ~ 9999	1> Current or Voltage input type will be appeared only 2> Max. input value will be transmitted into the dSPH
Min. display value setting 最小顯示值設定 — dSPL / 0 Press SET	-999 ~ 9999	1> Current or Voltage input type will be appeared only 2> Min. input value will be transmitted into the dSPL
Process current of heater 實際加熱器輸出電流值 — C t u / 0.00 Press SET	0 ~ 99.99	1> Range: 0.00 ~ 99.99 A
Heater break setting 加熱器斷線電流設定值 — H b / 1.00 Press SET	0 ~ 99.99	1> Range: 0.00 ~ 99.99 A 2>「**C t u**」＜「**H b**」→ **AL2 ON**
CT Low limit setting CT最小值設定 — C t L / 0.00 Press SET	0 ~ 99.99	1> Range: -9.99 ~ 99.99 2> Offset of CT current
CT High limit setting CT最大值設定 — C t h / 30.00 Press SET	0 ~ 99.99	1> Range: 0.00 ~ 99.99 2> To set the max.CT current
Ramp control setting 溫升速率控制 — r A P / 0 Press SET	0 ~ 9999	1> Range: 0 ~ 9999 ℃ or ℉ / minute 2> Rap=0: Without Ramp control function
Min. output volume setting 最小輸出量設定 — L o t / 0 Press SET 3 sec	0 ~ 100%	1> Range: 0 ~ 100% 2> Setting of min. output volume
Soft start setting 緩起動設定 — SV2 / 0 Press SET	-999 ~ 9999	1>「SV2」= 0: Without soft start function 2>「PV」<「SV2」: Fixed at manual output volume 3>「PV」≧「SV2」: Output volume controlled by PID

■ Mode of alarm / 警報模式【NT-□□】

Alt	Description / 警報說明	Alt	Description / 警報說明	Alt	Description / 警報說明
0		1		2	
3		4		5	
6		7		8	
9		10		11	
12		13		14	
15		16		17	
18		19	Non-used	20	
21		22		23	
24		25		26	

1.「ALt=15」: t = ON time of AL2 for cooling, OFF time is controlled by PID.
2.「ALH」: Hysteresis of alarm. Ex. PV≧(SV+AL1)→AL1 ON, PV＜(SV+AL1-ALH)→AL1 OFF
3.「tnu」= Process time of tnr, if「tnu≧tnr」→ AL2 is turned ON or OFF

■ Mode of alarm / 警報模式【NT-□□-CT & eTC-48 & NT-22】

Alt	Description / 警報說明	Alt	Description / 警報說明	Alt	Description / 警報說明
0		1		2	
3		4		5	
6		7		8	
9		10		11	

1＞「Alt = 11」: t = ON time of AL for cooling, OFF time is controlled by PID.
2＞「ALH」: Hysteresis of alarm. Ex：PV≧（SV+AL1）→AL1 ON；PV＜（SV+AL1-ALH）→AL1 OFF
3＞ NT-22□-CT: HB alarm output is AL1
4＞ NT-48□-CT: HB alarm output is AL2

Connection diagram / 接線圖

NT - 22-□□



NT – 48-□□



NT - 20-□□



NT – 21-□□



NT – 72-□□E



NT – 96-□□E



Attachment / 附件

CT-06: Load current 10 A max



CT-09: Load current 30 A max.



CT-100: Load current 100 A max.



■ Outline dimension / 外形圖

NT - 22-□□



NT – 48-□□



NT - 20-□□



NT – 21-□□



NT – 72-□□E



NT – 96-□□E



Specification may be modified without notice in advance. (2012/10/12)